

TIMELINE FOR THE OUTGAS PROCEDURE
(00/263 - 00/265)

DAY 263

VNORMOUTGAS procedure started	
VSCNDR OFF	Already Off
15 W Heater OFF	Already Off
8.5 W Heater ON	17:14:08
S VRADCDRL procedure called	
VRADCDOOR DRIVEA	17:12:49
VRADCDOOR CLOSE	17:12:49
S VRADCDRL procedure completed	
VRADCDOOR OUTGAS	17:12:54
VINSTGHTR OFF	17:13:11
VOUTSTGHTR OFF	17:13:20
VOUTGAS ENABLE	17:13:27
VMTRNHTRA ON	17:13:37
VNORMOUTGAS procedure completed	

DAY 264

Wait until Mounting Ring Temperature is > 25°C

VOUTGAS_HTRS procedure started	
VOUTSTGHTR ON	01:07:09
VOUTGAS_HTRS procedure completed	

Wait until Intermediate Stage Temperature is > 289°K

VOUTGAS_HTRS procedure started	
VINSTGHTR ON	02:38:27
VOUTGAS_HTRS procedure completed	

DAY 265

Wait until the Outgas Period has passed (Determined by Scientists, 30 hours)

VINITOUTGAS_END procedure started	
VINSTGHTR OFF	12:51:19
VOUTSTGHTR OFF	12:51:25
VINITOUTGAS_END procedure completed	

VRADCDROP procedure started	
VRADCDOOR OPEN	12:55:58
VRADCDROP procedure completed	

Wait until Intermediate Stage Temperature is < 220°K

VOUTGAS_HTRS procedure started	
VMTRNHTRA OFF	16:16:35
VOUTGAS DISABLE	16:16:35
VOUTGAS_HTRS procedure completed	

VMSISSMD procedure started	
VTIMEPATCH1	16:17:26
VTIMEPATCH2	16:17:38
VSCNDRV ON	16:17:51
VMSISSMD procedure completed	